



1/7




FIG. 1




FIG. 10




FIG. 2




FIG. 3

FIG. 4




FIG. 5




FIG. 6




FIG. 7






FIG. 8

FIG. 9



Example of assigning significant Pressure Drop across CV




FIG. 11




FIG. 12




FIG. 13A




FIG. 13B




FIG. 13C

FIG. 14




FIG. 15





FIG. 16